Temperature & Humidity Sensor



* Please read this manual carefully before use and keep it for future reference.

1

Product parameter

Size:	70* 24* 19 mm
Battery:	LRO3-1.5V/AAA*2
Wireless type:	WiFi / ZigBee
Measure Range:	-20℃ - 60℃ 0%RH-100%RH
Measure Accuracy:	±1℃ ±5% RH
Alarm mode:	APP notification push

Feature:

- Intelligent Linkage
- Temperature unit ℃ and ℉ switch
- Alexa / Google compatible

2

How to set up:

1. First scan QR code with your smartphone, or search "Smart Life" app in Google Play Store or APP Store to download and install app.

Available on the App Store

Get it on Google Play

2. Register the app with email address, then click "Home" "+" on the app interface or click "Add Device".

WiFi TH Sensor Connection

3. There are two ways for user to connect WIFI with sensor:
① **Bluetooth mode**
② **EZ mode.**



3

① Bluetooth mode: First turn on the bluetooth in mobile phone → open smart life app and choose "+" → long press reset key for 5 seconds → the LED indicator will flash rapidly. Then will see "Devices to be added:1" on mobile app. Finally press "Go to add", it will connect the Wi-Fi network automatically.



4

① EZ Mode: (Easy-Connect Network, here called EZ mode): long press reset key for 5 seconds. the LED indicator will flash rapidly. Then select the "EZ mode" of app in phone, then press "Next". Finally the sensor will enter the automatic network.



5

ZigBee TH sensor connection:

① First to choose the zigbee gateway that you had already connected wifi in smart life app. Then click the "Gateway" and click " Add subdevice"→ Long press reset key of T&H sensor for 5 seconds , the LED indicator will flash rapidly → Search device → Added successfully.



6

② . After added successfully, click the sensor icon to enter the app interface and do some setting.

Notice:

This device only can work along with a Zigbee Gateway. You need to connect wifi with a zigbee gateway successfully before use such zigbee T&H sensor.

7

4. Intelligent Linkage
When the ambient environment change, you can do intelligent linkage. For example, the air conditionor will be on automatically when the room temperature surpass 35℃. And the humidifier will spray when the humidity is lower than 20% RH.



8

5. Share devices
You can share your added devices with your family members, so they can also monitor the ambient environment.

6. Temperature Unit Selection in APP
You can choose ℃ or ℉ as the temperature unit through app.

7. Third-party Voice Control
Works with amazon alexa, google assistant.

9